




ConvoUpdate V6.00 & V5.19

User guide


Installation of ConvoUpdate

1. - Download and Extract the Zip file in a new directory on your computers hard disc



+3 Standard -
Software
V6.0_V5.19.zip

2. - Start the program by execute the ConvoUp.exe



Clues to ConvoUpdate

- Update has to execute for SM and BM software together
- texts, character sets and cookbooks will be uploaded for all available languages
- Update-process lasts 5 till 8 minutes depending on complexity
- old cookbooks will delete and are nonreversible
- Before update process:
 - shut off the Convotherm
 - remove the X12 connector at SM
 - and connect the RS232 cable between the PC/laptop and SM
- Please perform a C06/new init after the update process (gas values have to reconfigure)

(do not forget to put in the X12-connector to SM)

Use of ConvoUpdate

Configure the COM port

Option for
+3 / mini up to 2018
or
mini from 2018

Update
Process starts

ConvoUp +3 V5.3

COM port
COM1

Language
English


Unit type
☒ +3/Mini <2018
☐ New Mini >2018

**Update
Start**

1. Switch off the main power from unit
2. Connect the PC via RS232 to the SM
3. Disconnect the X12 from SM


CONVOTHERM

Change the language




Select the language

Language changed!




ConvoUpdate in progress...




The progress bar
should refresh
all 10 till 15
seconds

Then, all is OK!

Update finished successful...





Installation procedure

1. - Installation of the driver from CD-ROM
2. - Connection between the USBtoSer adapter and PC
3. - Configuration of the COM interface (Information next page)
4. >> Ready for action <<

